

### Single Phase Voltage Regulator Controller for Motorbike


#### **Features**

- Adaptive to single-phase magneto
- Zero Crossing regulation
- Over voltage protection with fast response
- Group wave modulation to keep each phase in balance
- Integrated internal regulator LDO
- Hot-plug protection for MOSFETs
- The voltage of the battery is adjustable
- Easy to use:only fewexternal components
- Available Packages: SOP-14

## **Description**


MST2101Q2KD is a voltage regulator controller adaptive for single phase high speed magneto applications. It receives power from magneto and regulates battery voltage through low Rdson MOSFETs, the MST2101Q2KD can keep energy conversion most efficient, and reduce regulator power loss and self heat. Multiple built-in protection mechanisms in MST2101Q2KD can prevent regulator and motorcycle load from damage. OVP circuit (Over Voltage Protection) can disconnect power from the load when voltage stress occurs on the load, especially on the battery absent condition. Hot Plug function integrated with MST2101Q2KD will prevent regulator from voltage spike damage due to loosing wires caused by driving vibration.

### **Typical Application**





## Pin Configuration and Functions



**Pin Functions** 

PIN	NAME	DISCRIPTION
1	TD	Detect whether the magnetic motor is working, connect a 47nF capacitor to the ground
2	DRV1	The switch driver of the first phase, connect to the NMOS's gate
3	PH1	The sense of the first phase, connect to the magneto first phase output through a 2 $K\Omega$ resistance
4	DRV2	The switch driver of the second phase, connect to the NMOS's gate
5	PH2	The sense of the third phase, connect to the magneto second phase output through a 2 $K\Omega$ resistance
6	DRV3	The switch driver of the third phase, connect to the NMOS's gate
7	PH3	The sense of the second phase, connect to the magneto second phase output through a 2 K $\Omega$ resistance
8	VCL	Voltage setting for output voltage lower limit
9	VCH	Voltage setting for output voltage upper limit
10	GND	GND of the chip and system
11	VREF	2.5V reference voltage, connect an external 100nFcapacitor
12	VCC	The internal power output of the chip, connect to a 10uF capacitor with voltage rating more than 25V
13	BAT	Battery terminal
14	VSEN	Battery voltage detection terminal



## **Absolute Maximum Ratings**

Characteristics	Symbol	Rating	Unit
PH1 to GND		-0.3 to 30	V
PH2 to GND		-0.3 to 30	V
PH3 to GND		-0.3 to 30	V
DRV1 to GND		-0.3 to 20	V
DRV2 to GND		-0.3 to 20	V
DRV3to GND		-0.3 to 20	V
BAT to GND		-0.3 to 40	V
VCC to GND		-0.3 to 20	V
TD to GND		-0.3 to 5	V
VCH to GND		-0.3 to 5	V
VCL to GND		-0.3 to 5	V
Operating Junction Temperature		-40 to 125	°C
Storage Junction Temperature		-40 to 150	°C
Thermal Resistance from Junction to ambient ( $\theta_{JA}$ )	SOP-14	125	°C/W

#### Note:

exceeding the range specified by the rated parameters will cause damage to the chip, and the working state of the chip beyond the range of rated parameters cannot be guaranteed. Exposure outside the rated parameter range will affect the reliability of the chip.

## **ESD Ratings**

Parameter	Description	Range	Unit
$V_{ESD}$	Human Body Model(HBM)	2	KV

#### Note:

JEDEC document JEP155 states that 500-V HBM allows safe manufacturing with a standard ESD control process. JEDEC document JEP157 states that 200-V CDM allows safe manufacturing with a standard ESD control process.

www.mst-ic.com Page 3-14 Rev.1-0 Jul. 2023



## **Electrical Characteristics**

( At  $T_A=25$ °C, VBAT=12V,unless otherwise noted )


Characteristics	Symbol	Conditions	Min	Тур.	Max	Units
Regulator output	$V_{\mathrm{BAT}}$	Connect to battery or load	14	14.5	15	V
Sleep current	$I_{SLEEP}$	The magneto stops working	-	50	-	μА
Static working current	$I_Q$	PH1=PH2=PH3=0	-	750	1000	μΑ
VCC operating voltage	V <sub>CC_MAX</sub>	PH1=PH2=PH3=0 $V_{BAT}=7V \sim 15V$	4		15	V
VREF voltage (A)			2.475	2.5	2.525	V
VREF voltage (B)	$V_{ ext{REF}}$	PH1=PH2=PH3=0 V <sub>BAT</sub> =7V to 15V	2.425	2.45	2.475	V
VREF voltage (C)		2	2.525	2.55	2.575	V
Phase voltage cross zero from negative to positive	V <sub>ZERO_P</sub>		3	5	7	mV
Phase voltage cross zero From positive to negative	$V_{\rm ZERO\_N}$		-7	-5	-3	mV
Over voltage protection	$ m V_{OVP}$		20	21	22	V
Drive current	I			30		mA

Note: (1) Dropout Voltage is the voltage difference between the input and the output at which the output voltage drops 2% below its nominal value.

www.mst-ic.com Page 4-14 Rev.1-0 Jul. 2023



# **Functional Block Diagram**





## **Detailed Description**

#### Overview

MST2101Q2KD is a voltage regulator controller adaptive for single phase high speed magneto applications. It receives power from magneto and regulates battery voltage through low Rdson MOSFETs, the MST2101Q2KD can keep energy conversion most efficient, and reduce regulator power loss and self heat.


Multiple built-in protection mechanisms in MST2101Q2KD can prevent regulator and motorcycle load from damage. OVP circuit (Over Voltage Protection) can disconnect power from the load when voltage stress occurs on the load, especially on the battery absent condition. Hot Plug function integrated with MST2101Q2KD will prevent regulator from voltage spike damage due to loosing wires caused by driving vibration.

MST2101Q2KD controller starts to regulate battery voltage when each phase current goes to zero crossing. With zero crossing regulation approach, the controller can greatly reducing switching loss avoiding regulator from heating, the most important, it greatly suppress electromagnetic interference in the system,

Through internal ON/OFF time sequence management, the power of each phase will be distributed to the battery and load evenly (Group Wave Modulation), avoiding the phenomenon of only one phase working while other phases idle. With the smooth and orderly control of each phase, the regulator ensures the reliability of the whole magnetic motor system.

When the magneto motor stops working, the controller will disconnect the whole circuit from battery guarantees low static current consumption of the battery and extend the life of the battery.

### **Zero-Crossing Detection**



- 1. ZERO\_1 and ZERO\_2 are each phase voltage zero-crossing detection signal
- 2. DRV\_1 and DRV\_2 are each phase driver output signal

Figure 1 Zero-Crossing Detection

The zero-crossing detection function is shown in figure 1. When the phase voltage signal is increased from negative voltage to 5mV, the output current of the corresponding phase of the magneto is judged as zero cross from negative to positive. The phase control circuit outputs low level, MOSFET is off and the voltage regulator starts to charge the battery.



In the same way, when the input phase voltage is dropped from the positive voltage to -5mv, the output current of the corresponding phase of the magneto is judged as zero cross from positive to negative. The phase control circuit outputs high level, MOSFET turns on, and the voltage regulator stops to charge the battery.

Suppose that N-MOSFET Rdson is about  $10m\Omega$ , then when the magneto output current rises up to 0.5A from negative, this phase is judged to zero cross from negative to positive; when the magneto output current drops to -0.5A from positive, this phase is judged as zero cross from positive to negative.

### Voltage modulation mode

MST2101Q2KD can regulate battery voltage by setting upper threshold voltage, medium threshold voltage, and lower threshold voltage. The setting formula for adjusting the upper and lower limits of the battery voltage is as following:

$$V_{ADJ_L} = \frac{R_6}{R_5 + R_6 + R_4} \times 2.5V \times 7.25 \ V$$

$$V_{ADJ\_H} = \frac{R_6 + R_5}{R_5 + R_6 + R_4} \times 2.5 \times 7.25 V$$

The setting formula for adjusting the medium value of the battery voltage is

$$V_{ADJ} = \frac{R_5 + 2R_6}{2 (R_5 + R_6 + R_4)} \times 2.5 \times 7.25 V$$

The battery voltage ripple is calculated as following:

$$V_{ADJ} = \frac{R_5}{R_5 + R_6 + R_4} \times 2.5 \times 7.25 \ V$$


The working principle of voltage regulator control method is shown in the figure 2. When the battery sense voltage is lower than the preset threshold voltage, the voltage regulator system will shut off the MOSFET of corresponding phase in the positive half cycle, and charge the battery or load.

In the same way, when the battery sense voltage is higher than the preset threshold voltage, the voltage regulator system will turn on the MOSFET of corresponding phase in the positive half cycle, and stop charging the battery or load.

Meanwhile, MST2101Q2KD has a built-in automatic equalization logic circuit, which guarantees each phase charging battery every cycle during the battery charging process, and avoids some phases working while other phases always idle.

www.mst-ic.com Page 7-14 Rev.1-0 Jul. 2023





#### NOTE:

- 1. ZERO 1 and ZERO 2 are each phase voltage zero-crossing detection signal
- 2. VM is the adjusting voltage detection signal
- 1. DRV 1 and DRV 2 are each phase driver output signal

Figure 2 Voltage modulation mode

#### Over voltage mode

The operating principle of over voltage mode is shown in Figure 3. When the phase voltage is higher than the over voltage protection voltage 21V, the MOSFET of the corresponding phase is immediately turned on, and the phase voltage is pulled down until the next cycle crosses zero, and then it returns to normal output.

### **Hot-plug Protection**


The magneto can cause sudden access or disconnection from the voltage regulator due to various reasons. If the power supply system of the whole chip has not been established yet, the output voltage spike of the magneto may damage the voltage regulator. For this abnormal usage, MST2101Q2KD has the hot-plug protection function that can prevent damage happening. At the moment that the voltage regulator is connected with the magneto motor, if the phase voltage is higher than 35V, the MOSFET of the corresponding phase is turned on immediately to avoid the voltage regulator damage. The hot-plug protection system is safe and reliable.

#### Shutdown state

When the magneto stops working, MST2101Q2KD goes into the sleep mode and does not consume current from the battery.

www.mst-ic.com Page 8-14 Rev.1-0 Jul. 2023






- NOTE: 1. 2. 1.
- ZERO\_1 and ZERO\_2 are each phase voltage zero-crossing detection signal OVP\_1 and OVP\_2 are each phase overvoltage detection signal VM is the adjusting voltage detection signal, VM\_3 is a logically processed signal for VM DRV\_1 and DRV\_2 are each phase driver output signal

Figure 3 Over voltage mode

www.mst-ic.com Page 9-14 Rev.1-0 Jul. 2023




# **Ordering And Marking Information**





www.mst-ic.com Page 10-14 Rev.1-0 Jul. 2023



# **Package Outline**









Symbol	Dimensions In Millimeters		Dimensions In Inches		
	Min	Max	Min	Max	
A		1.750		0.069	
A1	0.100	0.250	0.004	0.010	
A2	1.250		0.049		
b	0.310	0.510	0.012	0.020	
С	0.100	0.250	0.004	0.010	
D	8.450	8.850	0.333	0.348	
Е	5.800	6.200	0.228	0.244	
E1	3.800	4.000	0.150	0.157	
e	1.270(BSC)		0.050(BSC)		
L	0.400	1.270	0.016	0.050	
θ	0°	8°	0°	8°	



# **Packing Information**





Туре	W(mm)	P(mm)	D(mm)	Qty (pcs)
SOP14	16.0±0.1 mm	8.0±0.1 mm	330±1 mm	2500pcs

www.mst-ic.com Page 12-14 Rev.1-0 Jul. 2023





# **Revision History and Checking Table**

Version	Date	Revision Item	Modifier	Function & Spec Checking	Package & Tape Checking
1-0	2023-7-12		Xingxiaolin	Xingxiaolin	Xingxiaolin

www.mst-ic.com Page 13-14 Rev.1-0 Jul. 2023



#### **IMPORTANT NOTICE**

MST INCORPORATED MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARDS TO THIS DOCUMENT, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION).

MST Incorporated reserves the right to make modifications, enhancements, improvements, corrections or other changes without further notice to this document and any product described herein. MST Incorporated does not assume any liability arising out of the application or use of this document or any product described herein; neither does MST Incorporated convey any license under its patent or trademark rights, nor the rights of others. Any Customer or user of this document or products described herein in such applications shall assume all risks of such use and will agree to hold MST Incorporated and all the companies whose products are represented on MST Incorporated website, harmless against all damages.

MST Incorporated does not warrant or accept any liability whatsoever in respect of any products purchased through unauthorized sales channel. Should Customers purchase or use MST Incorporated products for any unintended or unauthorized application, Customers shall indemnify and hold MST Incorporated and its representatives harmless against all claims, damages, expenses, and attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized application.

Products described herein may be covered by one or more United States, international or foreign patents pending. Product names and markings noted herein may also be covered by one or more United States, international or foreign trademarks.